

PHONE DESCRIPTION	TECHNICAL DESCRIPTION	CALCULATION PHONE FROM *.fnx, *.log, *.bcl, *.sha files.	
	CPU TYPE	CONNECTION INTERFACE	ONLY 15 NCK
1280 (RM-647) unlock	Infineon X-Gold 102/110	-	Yes
1616 (RH-125) unlock	Infineon X-Gold 102/110	-	Yes
1800 (RM-653) unlock	Infineon X-Gold 102/110	-	Yes
2690 Classic (RM-635) unlock	RAPS v3.03 PA	JAF/UFS	Yes
2700 Classic (RM-561) unlock	RAPS v3.03 PA	JAF/UFS	Yes
2710 Navi (RM-586) unlock	Broadcom	USB	Yes
2730 Classic (RM-578/579) unlock	RAPS v3.03 PA	JAF/UFS	Yes
2710c (RM-586) unlock	Broadcom	USB	Yes
2710b-2 (RM-586) unlock	Broadcom	USB	Yes
3600 Slide (RM-352) unlock SW: v56.26 and v57.23	RAPS v3.03 PA	JAF/UFS	Yes
3710a-1 (RM-509/510) unlock	RAP3Gv4	USB	Yes
3711a (RM-511) unlock	RAP3Gv5	USB	Yes
3711a-1 (RM-511) unlock	RAP3Gv6	USB	Yes
3720 Classic (RM-518) unlock	RAPS v3.03 PA	JAF/UFS	Yes
Nokia 100 (RM-130) unlock	Infineon X-Gold 102/110	-	Yes
Nokia 113 (RM-871) unlock	Infineon X-Gold 102/110	-	Yes
Nokia 500 (RM-750) unlock	RapuYama v21	USB	Yes
5130 XpressMusic (RM-495) unlock	RAPS v3.03 PA	JAF/UFS	Yes
5230 (RM-588/593/594/625/629) unlock	RAPIDO	USB	Yes
5232 (RM-588/593/594/625/629) unlock	RAPIDO	USB	Yes
5233 (RM-588/593/594/625/629) unlock	RAPIDO	USB	Yes
5250 (RM-684) unlock	RAPIDO	USB	Yes
5320 (RM-409/417) unlock	RAPIDO	USB	Yes
5330 (RM-479/478) unlock	RAP3Gv4	USB	Yes
5530 (RM-504) unlock	RAPIDO	USB	Yes
5630 (RM-431) unlock	RapuYama v11	USB	Yes
5730 (RM-465) unlock	RAPIDO	USB	Yes
5800 (RM-356) unlock	RAPIDO	USB	Yes
600 (RM-701) unlock	RapuYama v21	USB	Yes
603 (RM-779) unlock	RapuYama v21	USB	Yes
6110 Navigator (RM-122) unlock	RAPIDO	USB	Yes
6120c (RM-243) unlock	RAPIDO	USB	Yes
6220c (RM-328) unlock	RAPIDO	USB	Yes
6300 (RM-217) unlock SW: v57.20	-	JAF/UFS	Yes

6303 Classic (RM-443) unlock	RAPS v3.03 PA	JAF/UFS	Yes
6303i Classic (RM-638) unlock	RAP3Gv4	USB	Yes
6500 Classic (RM-265) unlock SW: v59.45	-	JAF/UFS	Yes
6500 Slide (RM-240) unlock SW: v59.60	-	JAF/UFS	Yes
6650 (RM-400) unlock	RAPIDO	USB	Yes
6700 Classic (RM-470) unlock	RapuYama v11	USB	Yes
6700 Slide (RM-576) unlock	RapuYama v11	USB	Yes
6710 Navigator (RM-491) unlock	RapuYama v11	USB	Yes
6720 Classic (RM-424) unlock	RapuYama v11	USB	Yes
6730 Classic (RM-547/566) unlock	RapuYama v11	USB	Yes
6750 Mural (RM-381) unlock	RapuYama v11	USB	Yes
6760s (RM-573) unlock	RAPIDO	USB	Yes
6790s (RM-492) unlock	RAPIDO	USB	Yes
6790s-1c (RM-599) unlock	RAPIDO	USB	Yes
700 (RM-670) unlock	RapuYama v21	USB	Yes
701 (RM-774) unlock	RapuYama v21	USB	Yes
702T (RM-730) unlock	RapuYama v11	USB	Yes
7020 (RM-497) unlock	Broadcom	USB	Yes
706 (RM-448) unlock	-	USB	Yes
7230 (RM-598/RM-604) unlock	RAP3Gv4	USB	Yes
808 PureView (RM-807)	RapuYama v21	USB	Yes
Asha 200 (RM-761/762) unlock	Infineon X-Gold 213	USB	Yes
Asha 201 (RM-799/RM-800) unlock	Infineon X-Gold 213	USB	Yes
Asha 203 (RM-832) unlock	Infineon X-Gold 213	USB	Yes
Asha 205 (RM-862/RM-863/RM-864) unlock	Infineon X-Gold 213	USB	Yes
Asha 206 (RM-872/RM-873) unlock	Infineon X-Gold 213	USB	Yes
Asha 300 (RM-781) unlock	RapuYama v21	USB	Yes
Asha 303 (RM-736) unlock	RapuYama v21	USB	Yes
Asha 306 (RM-767) unlock	RapuYama v21	USB	Yes
Asha 311 (RM-714) unlock	RapuYama v21	USB	Yes
C1-01 (RM-607/608) unlock	Infineon X-Gold 213	USB	Yes
C1-02 (RM-643/RM-644) unlock	Infineon X-Gold 213	USB	Yes
C1-03 (RM-607) unlock	Infineon X-Gold 213	USB	Yes
C2-00 (RM-704) unlock	Infineon X-Gold 213	USB	Yes
C2-01 (RM-721/722) unlock	RAP3Gv4	USB	Yes
C2-02 (RM-692) unlock	Infineon X-Gold 213	USB	Yes
C2-02.1 (RM-693) unlock	Infineon X-Gold 213	USB	Yes
C2-03 (RM-702) unlock	Infineon X-Gold 213	USB	Yes
C2-05 (RM-724/725) unlock	Infineon X-Gold 213	USB	Yes
C2-06 (RM-702) unlock	Infineon X-Gold 213	USB	Yes
C2-07 (RM-692) unlock	Infineon X-Gold 213	USB	Yes
C3-00 (RM-614) unlock	Broadcom	USB	Yes
C3-01 (RM-640/776) unlock	RapuYama v11	USB	Yes
C5-00 (RM-645/688) unlock	RapuYama v11	USB	Yes
C5-02 (RM-745) unlock	-	USB	Yes

C5-03 (RM-697/744) unlock	RapuYama v11	USB	Yes
C5-03.2 (RM-719) unlock	-	USB	Yes
C5-04 (RM-720) unlock	-	USB	Yes
C6-00 (RM-612/624) unlock	RAPIDO	USB	Yes
C6-01 (RM-601/718) unlock	RapuYama v11	USB	Yes
C7-00 (RM-675/691) unlock	RapuYama v11	USB	Yes
C7-00s (RM-749) unlock	-	USB	Yes
E5-00 (RM-632/634/699) unlock	RapuYama v11	USB	Yes
E52 (RM-469/481) unlock	RapuYama v11	USB	Yes
E55 (RM-482) unlock	RapuYama v11	USB	Yes
E6-00 (RM-609) unlock	-	USB	Yes
E63 (RM-437/449/450/600) unlock HASH: 47x, C7x	RAPIDO	USB	Yes
E66 (RM-343/345/420/494) unlock HASH: 47x, C7x	RAPIDO	USB	Yes
E7-00 (RM-626) unlock	RapuYama v11	USB	Yes
E71 (RM-347) unlock	RAPIDO	USB	Yes
E71-1 (RM-346/357/407/493) unlock HASH: 47x, C7x	RAPIDO	USB	Yes
E71x (RM-462) unlock HASH:47x, C7x	RAPIDO	USB	Yes
E72 (RM-529/530/584/) unlock HASH: 25xx	RapuYama v11	USB	Yes
E73 RM-568	RapuYama v11	USB	Yes
N8-00 (RM-596) unlock	RapuYama v11	USB	Yes
N78 (RM-235/236/342) unlock	RAPIDO	USB	Yes
N79 (RM-348/349/350) unlock	RAPIDO	USB	Yes
N81 (RM-179) unlock	RAPIDO	USB	Yes
N81 8GB (RM-223/256) unlock	RAPIDO	USB	Yes
N82 (RM-313/314) unlock	RAPIDO	USB	Yes
N85 (RM-333/334/335) unlock	RAPIDO	USB	Yes
N86 (RM-484/485/486) unlock	RAPIDO	USB	Yes
N97 (RM-505/506/507) unlock	RAPIDO	USB	Yes
N97 Mini (RM-553/555) unlock	RAPIDO	USB	Yes
T7-00 (RM-679) unlock	-	USB	Yes
X2-00 (RM-618) unlock	Broadcom	USB	Yes
X2-01 (RM-709) unlock	Broadcom	USB	Yes
X2-01.1 (RM-717) unlock	Broadcom	USB	Yes
X2-03 (RM-709) unlock	Broadcom	USB	Yes
X2-05 (RM-772) unlock	Infineon X-Gold 213	USB	Yes
X3-00 (RM-540) unlock	RAP3Gv4	USB	Yes
X3-01 (RM-687) unlock	RAPUYAMA	USB	Yes
X3-02 (RM-639/775) unlock	RapuYama v11	USB	Yes
X5-01 (RM-627/648) unlock	RapuYama v11	USB	Yes
X6-00 (RM-551/559) unlock	RAPIDO	USB	Yes
X7-00 (RM-707) unlock	RapuYama v11	USB	Yes
X7-00.1 (RM-659) unlock	RapuYama v11	USB	Yes